

# *Scan Alarm*

## **ANASCAN SOFTWARE MANUAL**

---

### **Home Office**

Analytical Technology, Inc.  
6 Iron Bridge Drive  
Collegeville, PA 19426  
Ph: (800) 959-0299  
(610) 917-0991  
Fax: (610) 917-0992  
Email: [sales@analyticaltechnology.com](mailto:sales@analyticaltechnology.com)

### **European Office**

ATI (UK) Limited  
Bank Chambers, 33 Stamford St.  
Mossley, Ashton-u-Lyne OL50LL  
Ph: 0800-018-4020  
+ 44 (0) 1457 832800  
Fax: + 44 (0) 1457 839500  
Email: [sales@atiuk.com](mailto:sales@atiuk.com)

---

# PRODUCT WARRANTY

Analytical Technology, Inc. (Manufacturer) warrants to the Customer that if any part(s) of the Manufacturer's products proves to be defective in materials or workmanship within the earlier of 18 months of the date of shipment or 12 months of the date of start-up, such defective parts will be repaired or replaced free of charge. Inspection and repairs to products thought to be defective within the warranty period will be completed at the Manufacturer's facilities in Collegeville, PA. Products on which warranty repairs are required shall be shipped freight prepaid to the Manufacturer. The product(s) will be returned freight prepaid and allowed if it is determined by the manufacturer that the part(s) failed due to defective materials or workmanship.

This warranty does not cover consumable items, batteries, or wear items subject to periodic replacement including lamps and fuses.

Gas sensors, except oxygen sensors, are covered by this warranty, but are subject to inspection for evidence of extended exposure to excessive gas concentrations. Should inspection indicate that sensors have been expended rather than failed prematurely, the warranty shall not apply.

The Manufacturer assumes no liability for consequential damages of any kind, and the buyer by acceptance of this equipment will assume all liability for the consequences of its use or misuse by the Customer, his employees, or others. A defect within the meaning of this warranty is any part of any piece of a Manufacturer's product which shall, when such part is capable of being renewed, repaired, or replaced, operate to condemn such piece of equipment.

This warranty is in lieu of all other warranties (including without limiting the generality of the foregoing warranties of merchantability and fitness for a particular purpose), guarantees, obligations or liabilities expressed or implied by the Manufacturer or its representatives and by statute or rule of law.

This warranty is void if the Manufacturer's product(s) has been subject to misuse or abuse, or has not been operated or stored in accordance with instructions or if the serial number has been removed.

Analytical Technology, Inc. makes no other warranty expressed or implied except as stated above.

# Contents

<b>Contents .....</b>	<b>4</b>
<b>Introduction .....</b>	<b>9</b>
ANASCAN Features.....	9
Computer Requirements.....	10
<b>INSTALLATION.....</b>	<b>11</b>
ANASCAN Files .....	11
File Locations.....	12
INSTALLATION PROGRAM.....	13
INSTALLATION MENU .....	14
Directory Paths .....	15
Grouping Channels .....	15
<b>START UP.....</b>	<b>17</b>
Quick Start Up.....	17
Start Up Optional Modes.....	17
Start Up Sequence.....	17
Default Start Up Values .....	18
Start Up Errors.....	19
Message.....	21
Solution .....	21
Message.....	22
Cause .....	22
<b>GENERAL SCREEN DISPLAYS.....</b>	<b>24</b>
Changing Data.....	25
Print Screen .....	25
<b>CHANNEL OVERVIEW .....</b>	<b>26</b>
Getting Here .....	26
Options.....	26
Function Keys.....	28
<b>EDIT.....</b>	<b>30</b>
Getting Here .....	30
Function Keys.....	30
<b>CHANNEL SETUP.....</b>	<b>31</b>
Getting Here .....	31
Function Keys.....	32
Parameters.....	32
<b>SYSTEM SETUP.....</b>	<b>36</b>
Getting Here .....	36
System Errors .....	37
System Software.....	38
Passwords.....	38
System Parameters.....	39
System Terminate.....	40
System Start Up .....	41
Data Logging.....	43
Scanner Comm. ....	44
Alarm Output Polarity.....	45

<b>JOB SETUP .....</b>	<b>46</b>
Getting Here .....	46
<b>VIEW ALARMS .....</b>	<b>47</b>
Getting Here .....	47
Function Keys .....	48
Alarm Screen Auto Switch .....	48
Audible Alarm .....	48
<b>TREND PLOT .....</b>	<b>49</b>
Getting Here .....	49
Function Keys .....	50
Trend Plot Setup Screen .....	50
Getting Here .....	50
Print Trend Plot Screen .....	52
<b>APPENDIX: Input Scaling .....</b>	<b>53</b>
Linear Input Scaling .....	53

## Overview

This manual describes how to install, setup, and operate ANASCAN. ANASCAN is DOS based software that allows you to program and monitor single or multiple Scanners from a single PC. Included is data logging and trend plotting.

### Using this Guide

This guide is intended for both experienced and inexperienced users. Experienced users may find some parts of this guide very simplistic; if that's you, please at least skim these parts to make sure you don't miss anything vital. If you are an inexperienced user, please read this guide carefully.

If you have any questions, please call Analytical Technology, Inc. at 1-800-959-0299.

The following describes each section.

- **Introduction:** Describes ANASCAN and its computer requirements.
- **Installation:** Covers how to install and setup ANASCAN.
- **Startup:** Describes program loading and startup errors.
- **General Screen Displays:** Provides an overview of the screen and typical screen responses.
- **Channel Overview:** Describes the channel overview screen.
- **Edit:** Describes the edit screen.


## C14 Scan Alarm Operations Manual

---

- **Channel Setup:** Gives an overview of the channel setup screen. Included are descriptions of system parameters.
- **System Setup:** Describes the system setup screen.
- **Job Setup:** Describes the job setup screen.
- **View Alarms:** Describes alarms and how to view them.
- **Trend Plot:** Covers trend plotting and reviewing trend plots.
- **Appendix:** Describes input scaling.

### System Block Diagram

The following shows the PC interface (with ANASCAN) to a Scanner.



### Safety

Analytical Technology has made every effort to ensure the reliability and safety of ANASCAN. Note that in any application failures can occur.

Good Engineering practices, electrical codes, and insurance regulations require that you use independent external safety devices to prevent potentially dangerous or unsafe conditions. Assume that ANASCAN can fail or that other unexpected conditions can occur.

For additional process safety, program the computer to automatically reload your desired operating parameters after a power failure. This safety feature however does not eliminate the need for other external, independent safety devices in dangerous situations.


In the event of a scanner reset, ANASCAN will reload the unit with the current values in computer memory. The user must ensure that this reset will be safe for the process. Use of ANASCAN does not eliminate the need for appropriate external, independent safety devices.

Please contact Analytical Technology immediately if you have any questions about system safety.

# Introduction

ANASCAN is a user friendly, menu driven software package. It interfaces to the C14 Scanner system to monitor inputs and alarms for up to 256 independent channels.

You may have only one Scanner or a plant wide system with numerous units. ANASCAN includes numeric and graphic displays, data and alarm printing, data and alarm logging in text or LOTUS compatible files, and graphic trending. It runs on an IBM AT286, 386, or 486, and true compatible computers. A question and answer format enables users to quickly define and setup any measurement or application.



---

### NOTE

ANASCAN is sold with a license agreement and can be operated only on one computer

---

## ANASCAN Features

- Process overview screens
- Channel setup screen, individual channel parameters editing
- Maintaining a directory of job files
- Displaying and logging process variable alarms
- Password protection for various levels of program
- Software grouping of Channels
- Graphic trend plotting of process variability points and output values in real time
- Definable startup sequences
- Power Failure recovery
- Printer and disk data and alarm logging



### Computer Requirements

Computer requirements for running ANASCAN:

1. IBM AT286, 386, 486 or other IBM Compatible Computer
2. Dos Version 3.3 or higher
3. Speed: 25 MHz or higher

This speed provides the best performance of the ANASCAN program; it enhances the response of the system to changes and maintains the best screen updates. However, it is not a factor in the performance of the system since this is maintained independently in each Scanner.

4. Memory: 580K bytes free memory.
5. Disk Drives: One 40MB hard Disk. One 5.25" and/or 3.5" floppy disk
6. Graphics Interface: EGA/VGA
7. RS-485 Serial Interface, Ultra 485 RS-485 card for Windows recommended



---

#### NOTE

Some Computers will not allow you to reassign the addresses of your serial ports. You will need one of the serial ports for the RS-485 Interface card.

---

8. Battery Backed up real time clock (usually battery backed CMOS chip)
9. EGA/VGA Monitor: The EGA interface card will allow color trend plotting even with a CGA monitor. The EGA/VGA monitor used with the EGA/VGA interface provides text displays making observation, full EGA or VGA is recommended.
10. A Graphics Printer is required for printing data and alarm logging features of ANASCAN. An IBM compatible printer, Citizen GSX-190 is recommended. If the printer is used, it must be ON LINE to operate the features of ANASCAN.

# INSTALLATION



---

**WARNING:**

It is your responsibility to ensure that the entire system is safe. Please read the safety warning on of this manual. If there is any possibility of an unsafe condition, use independent safety devices

---

## ANASCAN Files

SCANINST.EXE – ANASCAN installation program

ANASCAN.EXE - a file that contains the main program software.

### *Support files:*

INSTAL.DAT – installation parameter data file

LPGRP.DAT – Channel grouping start up data file

SYSSU.DAT – system setup data file

STATUS.DAT – system start up data file

DIGIO.DAT – digital I/O screen data

DLOG.DAT – data logging data file

GRPMO.DAT – group set up data file

HDR.WK1 – LOTUS header set up file

PLOT.DAT – plot parameters data file

### *Files created by ANASCAN:*

XXXXXXXX.J## - group job directory data file

NEWXX.PLT – plot files which were created within the last 24 hours

OLDXX.PLT – old plot files


PXXXXXXX.TXT or WK1 process logging files

AXXXXXXX.TXT or WK1 alarm logging file

### File Locations

#### *Hard disk systems:*

Analytical Technology recommends setting up directories as follows:



C:\ANASCAN – To contain the operating program and system data.

INSTAL.DAT  
LPGRP.DAT  
ANASCAN.EXE  
SCANINST.EXE  
OLDOV.PLT  
OLDPV.PLT  
OLDSP.PLT  
NEWPV.PLT  
NEWSP.PLT  
NEWOV.PLT  
HDR.WK1

C:\ANASCAN\ALARMLOG – To contain alarm-logging files generated by ANASCAN

C:\ANASCAN\DATALOG – To contain data-logging files generated by ANASCAN.

C:\ANASCAN\JOBS – To contain job and system parameter files.

DIGIO.DAT  
DLOG.DAT  
GRINFO.DAT  
PLOT.DAT  
STATUS.DAT  
SYSSU.DAT  
ATI.JOO

### INSTALLATION PROGRAM


The installation program, SCANINST.EXE, customizes the ANASCAN program for the application. Type C:SCANINST. The installation screen appears and enables you to select parameters used by ANASCAN.

SCANINST.EXE stores the program setup parameters in a file called INSTAL.DAT. When run, the SCANINST program reads the INSTAL.DAT file from the default disk directory. If both files are in the same disk directory, enter the directory and type SCANINST.

If the SCANINST.EXE and INSTAL.DAT file are in different directories, enter the disk directory containing INSTAL.DAT and type SCANINST preceded by the path to the disk directory containing SCANINST.

If the installation program cannot find INSTAL.DAT, an error appears. Verify the location of INSTAL.DAT file.

INSTALLATION MENU



Number of Channels

ANASCAN displays 16 channels with system numbers. The system channel numbers associated with the Scanner channels are indicated in the installation program as the Begin Channel and End Channel for each Scanner.

### Directory Paths

#### *Job/Parameters path*

This is the path to the disk directory containing the Job and System Parameters Data Files. The path would normally be:

C:\ANASCAN\JOBS\ or \JOBS\ Notice that the last “\” is added automatically.

#### *Data Logging Path*

This is the path to the disk directory containing the LOTUS or text (ASCII) data logging files generated by ANASCAN. This directory must exist before running ANASCAN and turning on data logging.

C:\ANASCAN\DATALOG\ or \DATALOG\ Notice that the last “\” is added automatically.

#### *Alarm Logging Path*

This is the path to the disk directory containing the LOTUS or Text (ASCII) alarm record files generated by ANASCAN. This directory must exist before running ANASCAN and turning On alarm logging.

C:\ANASCAN\ALARMLOG or \ALARMLOG\ Notice that the last “\” is added automatically.

### Grouping Channels

Grouping inputs allows you to divide your system into subsystems. You can group channels with a common purpose according to your specific application requirements. One group might be for a gas detector or a group of gas detectors; another group might be for common Jobs shared between devices.

Only the channels of one group are displayed on the Overview screen at a time. The job parameters are uploaded or downloaded to an individual group independently. The number of controllers with their total number of channels must match the number of channels in the grouping. The channel numbering depends upon the type of input selected in the SCANINST program.

After assigning the channel numbers to a group, select a type number of two digits up to 99. This number is the job directory number for the group and its channels. All groups with the same type number will be assigned to the same job directory. Creating a new type number creates a new job directory number in the ANASCAN program.

## Group Menu

[illegible]

## General grouping rules

- Create a group when you need to have the channels on the same Overview screen.
- Assign the channels to the group you want to have on the same Overview screen.
- Create a type number for the new group. This type number can be assigned to more than one group if they share common jobs through the ANASCAN.EXE program. However, when using the same type number for groups, the number of channels must match. Otherwise, a new type number must be used.



## NOTE

Type value is used to store jobs specific for that type. The Default job is only stored under type 01.

# START UP

## Quick Start Up

- Ensure time and date is correct in your computer.
- Type: ANASCAN. Job Select screen appears.
- Type a job's name. When starting the first time, enter DEFAULT.
- Type **D** (download) to transfer the job **FROM** the computer **TO** the Scanner. Type **U** (upload) to transfer the job **FROM** the Scanner **TO** the computer.
- Overview screen appears.

## Start Up Optional Modes

You can start ANASCAN in certain modes by adding parameters to the command at start up. These command line options include:

- /e  
Operates the program in Edit mode. The program operates normally but it does not communicate with the Scanner. You can operate the program in Edit mode without any hardware connected to the computer. This mode is useful for initial familiarization, training, and Off Line job editing.
- /c  
Forces the graphics display into CGA mode. This is necessary on some computers that are not truly IBM compatible.
- /d  
Operates the program in the Debug mode. This is useful in debugging communications problems. Do not use it for normal operations. All communications between the computer and the scanner are displayed on the printer. Therefore, in order to use this mode, the printer must be connected and ready.

You can use capital or small letters in the command line, and more than one command line option at a time. For example

Typing ANASCAN /E /C [ENTER] will operate the program in Edit mode with CGA graphics.

## Start Up Sequence



## C14 Scan Alarm Operations Manual

---

- The program checks the computer system hardware and the access to the system disk files.
- The program verifies communications to each Scanner in the system and their versions.
- Job Directory screen appears

Screen:Job Select		Group:Eng Test Job:ATI		07-20-98 14:15:06	
<b>JOB DIRECTORY</b>					
ATI LION TIMET DEFAULT					
<b>PROCESS</b> OK		<b>SYSTEM:</b> OK		<b>F1</b> Load Job	
				<b>F2</b> Save Job	
				<b>F3</b> Delete Job	
				<b>ESC</b> Return	

- The program prompts for the job to run. ANASCAN program is supplied with a job named DEFAULT which contains all the default parameters and setups. When starting the first time, enter the job name DEFAULT.

---

### WARNING



When the Scanner is monitoring, upload to install parameters into the ANASCAN operating program. Downloading will install factory default values. For initial testing in the Edit mode, enter Download.

---

- After the downloading sequence is complete, the program displays the Overview screen. If there is a problem in the program start up, see; *start up errors* on page 17 of this section.

### Default Start Up Values

The program is shipped to you containing several parameters, which are set to initial factory default values. These should be set to desired values by supervisory personal, and they include:

- Passwords
- Program startup sequences

See *System Setup* for detailed information.

### Start Up Errors

During Start up, various error messages may appear. The following tables describe these messages, their causes and solutions.

#### *Memory allocation errors*

ANASCAN allocates computer memory for the channel parameters, based on the number of channels and options in the system. When ANASCAN reads in the system data files and finds there is not sufficient memory, these messages may appear.

Message	Cause	Solution
Insufficient Memory	Not enough memory to allocate Data arrays required to run the Program. The program cannot run and it terminates.	<ul style="list-style-type: none"><li>• Check the memory by running the DOS program SCANDISK. At least 580K should be free.</li><li>• Make sure your computer has at least 640K memory, and remove any memory resident programs and drivers. Check AUTOEXEC.BAT file to see if it installs any memory resident programs. Remove these programs, and re-boot the computer.</li></ul>
MEM ERROR: Alarm Queue	Not enough memory to allocate the alarm log memory. The program operates, but the view alarms screen does not display alarm queue.	<ul style="list-style-type: none"><li>• Same as above</li></ul>

## C14 Scan Alarm Operations Manual

---

Trend Logging Disabled	Not enough memory to allocate some or the entire trend logging memory queues. The program operates normally, but the trend plotting is not available.	<ul style="list-style-type: none"><li>• Same as above</li></ul>
------------------------	---	---

## C14 Scan Alarm Operations Manual

---

### *Disk File Errors*

While reading in the system files, several reading errors can occur. The system files are SYSSU.DAT, INSTAL.DAT, and PLOT.DAT. ANASCAN cannot run without these files.

Message	Cause	Solution
ERROR WHILE READING DATA FILE: xxxxxxxl FILE NOT FOUND	The system file does Not exist on the indicated disk and directory path.	The INSTAL.DAT file should be on the Default drive directory. The other system files should be on the data file drive and directory path as set in the installation program. If these files are not in the right directories, copy the system files from the backup disks to the appropriate directories.
ERROR WHILE READING DATA FILE: xxxxxxxx Drive not ready Read fault General failure or Access failure	There is a disk drive hardware access failure.	Run SCANDISK or other diagnostic programs to verify that there are no disk drive problems.
ERROR WHILE READING DATA FILE: xxxxxxxx Path not valid or Invalid disk drive	The Data disk path that you set in the SCANINST installation program is not valid.	Run SCANINST and verify that the drive and directory path exists and are valid. Do not forget to verify that “\” is at the end of the path entry.
INVALID DATA FOUND ON DATA FILE: xxxxxxxx	There is corrupted or invalid data in the disk file.	Copy the original data file sent with ANASCAN from the backup disks.

## C14 Scan Alarm Operations Manual

### *Extended start up sequence errors*

ANASCAN reads in the status file STATUS.DAT which contains information saved by ANASCAN the last time it was running. Several errors can occur when reading this file.

Message	Cause	Program Action	Solution
Could not find STATUS.DAT start up file	The file could not be found on the data file disk directory set by SCANINST. The file may have been erased or corrupted.	ANASCAN continues with the start up, but since there is no power failure information available, ANASCAN assumes the Power Failure Over Limit action, and starts in that mode	As the program is running, the STATUS. DAT file will be established. Therefore, subsequent starts should have no problem
Invalid data value on STATUS.DAT start up file	The file contains some invalid data, and ANASCAN assumes that the file was corrupted.	Same as above.	Same as above.
Power Failure Recovery System clock Error	The current system time/ data as saved in the STATUS.DAT file were not in a valid range. The computer system clock is not set to valid time and date.	Same as above.	The automatic power failure recovery feature of ANASCAN requires a correct clock/calendar system. While the computer boots up, verify the following: <ul style="list-style-type: none"><li>• There is a battery backed up clock/calendar in the system.</li><li>• The battery is good.</li><li>• Time and date values are correctly loaded.</li></ul>

### Communications Problems

Message	Cause	Solution
Failed Communications to Scanner. Abort start up (Y/N):	ANASCAN cannot communicate with one of the Scanners during the initial system communication check or during the job downloading / uploading	<ul style="list-style-type: none"><li>• Verify that the communications port set in SCANINST is the one actually connected to the Scanner.</li><li>• Verify that the communication parameters (baud rate and error checking mode) set in the installations program are those set in the Scanner. The Scanner communications parameters are set using the front panel keys while in the GLOBAL menu.</li><li>• Verify that the address of each Scanner is unique (for multiple Scanner systems).</li><li>• Verify that the correct version of ANASCAN is running for the Scanner being used.</li><li>• Verify that the wiring is done correctly to the Scanner and the computer.</li></ul>



#### NOTE


See the respective Scanner hardware manual for assistance in checking the communication parameters and verifying the communication wiring.

- If there is more than one Scanner in the system, ANASCAN will try supervising those Scanners which are operating and communicating correctly. After start up ANASCAN periodically rechecks communications to the failed Scanner.
- By continuing the start up, the Scanner not communicating will be listed by address on the System Errors window in the System Setup Screen. Check the unit listed on the screen. Be sure the address is correct as set on the Scanner.

## GENERAL SCREEN DISPLAYS

Certain characteristics are maintained on all ANASCAN screens as follows:

Title line. Includes screen's name, current channel and job, and the time and date. When in Edit mode, "Edit Mode" will appear at this location.



Process status box. Four possible messages:

1. Process OK (green)
2. Process warning (yellow). There is a warning on at least one channel.
3. Process alarm (blinking red). An alarm condition on at least one channel has not been acknowledged.
4. Process alarm (red). An alarm condition on at least one channel, All alarms have been acknowledged.

System status box. Reports problems of communications, printer access, or data logging disk access. Two possible messages:

1. System OK
2. In case of a problem, the appropriate message (red).

### Changing Data

- Use the cursor to enter data in the editing screens.
- Move the cursor to the variable you want to change. An editing prompt appears at the bottom of the screen with a blue background new value box. The allowable range of the variable is listed below the new value box.
- Type the new desired value into the new value box.
- Press Enter. The new value will replace the original one, and will be downloaded to the Scanner. If you made a mistake in entering the value and have not pressed Enter, use the backspace key to correct.
- Use the F4 key to enter the Job Setup screen and save the changes. If you do not, upon a new start up, the Job data file will be read from the disk along with the old parameter.

---

#### NOTE



The new value is sent first to the respective scanner. The display changes only after the scanner accepts the new value. This may cause a slight delay after entry, especially on slow computers or when a large number of scanners are connected.

---

### Print Screen

- You can print all ANASCAN screens on an IBM graphics compatible dot matrix printer.
- Use the Print Screen key. When print screen is initiated, a copy of the current screen is transferred to a buffer and the screen will be printed as a background task. The program continues operating and you can display other screens while printing a screen.
- When printing the Trend plot Screen, you will be asked for a title before printing the screen.



# CHANNEL OVERVIEW

The Channel Overview screen provides an overview of the process information. It is not password protected and is available at all times for anyone who wishes to monitor the process variables.

## Getting Here


This screen appears automatically after start up.

## Options

The Overview screen has four display screens. Use the F6 key to switch between displays.

1. Four-channel graph display. Each channel includes a range of parameters.


Single Channel Display \*




\* The Single Channel Display includes the channel name, setpoint, process variable, alarm messages, warning and alarm setpoints.

# C14 Scan Alarm Operations Manual

2. 16-channel display in a table with 7 listed channel parameters.  
1 selectable channel scanner display.



3. 32-channel display in a table with 4 Channel parameters.  
1 selectable channel scanner display.



## C14 Scan Alarm Operations Manual

4. Digital I/O screen. This screen shows the status of your digital inputs and outputs

Screen:Digital I/O			Group:Eng Test Job:ATI			07-20-98 14:58:06		
			SCANNER 1 DIGITAL INPUT/OUTPUT					
DIGITAL INPUT			DIGITAL OUTPUT					
1	Job S1	HIGH	1 Zone 1A	ON	17	OFF	33	OFF
2	Job S2	HIGH	2 Zone 1B	ON	18	OFF	34	OFF
3	Job S3	HIGH	3 Zone 1C	ON	19	OFF	35 Globl Al	OFF
4		HIGH	4 Zone 2A	ON	20	OFF		
5		HIGH	5 Zone 2B	ON	21	OFF		
6		HIGH	6 Zone 2C	ON	22	OFF		
7		HIGH	7 Zone 3A	ON	23	OFF		
8		HIGH	8 Zone 3B	ON	24	OFF		
			9 Zone 3C	ON	25	OFF		
			10 Zone 4A	ON	26	OFF		
			11 Zone 4B	ON	27	OFF		
			12 Zone 4C	ON	28	OFF		
			13	OFF	29	OFF		
			14	OFF	30	OFF		
			15	OFF	31	OFF		
			16	OFF	32	OFF		

PROCESS	SYSTEM:	F1	F3	F4	F5	F6	F7
OK	OK	Edit	System	Job	View	Change	Trend
		I/O	Setup	Setup	Alarms	Display	Plot

### Function Keys

For easy access from the Overview screen to all other screens, use the function keys as shown below:

Key	Function
TAB	Change group. Switch to a new group in any screen. You do not need to go back to Overview screen.
F1	Edit screen. Change set-point
F2	Channel Setup screen. Display and edit all channel parameters.
F3	System Setup screen. Display and edit various system parameters (passwords, disk and printer data logging, start up, etc.)
F4	Job Setup screen. Select, save and delete jobs
F5	View alarms. Display on-screen alarm log. System Setup allows selecting automatic to this screen in case of an alarm
F6	Switch displays. Change the Overview screen display to one of its 4 options.
F7	Trend logging. Display the graphic trend plot.

## C14 Scan Alarm Operations Manual

---

- Press ESC to view the next Group Overview screen. If you wish to view another group, move the cursor to that group and press ESC.
- If not all the channels are visible (in a large system), use the PgUp/PgDn keys to view the other channels.
- The Overview screen is automatically updated as data is collected from the Scanner. Measured data is displayed in engineering units.
- Normal readings are **green**, warnings are **yellow**, and alarms are **red**.
- If you edit the Scanner at its front panel, ANASCAN displays the word “locked” in the single channel Faceplate and puts the letter “L” beside the process variable in the Channel Table for the channels on the edited scanner. Once the front panel editing is complete, the display returns to normal.

EDIT


The Edit screen enables you to change the setpoint of the single channel display you have selected.

The Edit screen uses the same format as the Overview screen, only here you can move the cursor to change the values. This screen is not password protected.

The Edit screen performs the same functions as change setpoint on the scanner front panel.

Getting Here

Press F1 from the Overview screen. You will enter an Edit screen with the same display as the screen you were in before pressing F1. The screen below is an Edit screen for the 16-channel display.



Function Keys

Key	Function
PgUp/PgDn	Display other channels for editing
Tab	Reach channels of other groups
ESC	Return to Overview screen


# CHANNEL SETUP

From the Channel Setup screen you can select inputs, assign channel names, and set the ranges and functions of alarms for each single channel display you have selected. Use this screen to change all available channel parameters.

Analytical Technology recommends that you protect this screen with a password. Use the F3 System Setup screen Password window.

## Getting Here

Press F2 from the Overview screen.




## Function Keys

Key	Function
F1	Copy all channel parameters into the channel currently displayed
F7	Display the Graphic Trend Plot of the channel. Press Esc to return to the channel Setup screen
PgUp/ PgDn	Change the display to other channels within the group.
TAB	Change the display to other groups. Available only when there is more than one group.
ESC	Return to Overview Screen

## Parameters


To review all the parameters available in this screen, we have divided it into three sections (shown in previous page): Channel Graph Display, Input Data, and Alarm Output Data.

### *Channel Graph Display*



## C14 Scan Alarm Operations Manual

### Input Data



Field Name	Selection	Notes
Input Type	L	Linear (see description)
	X	Skip
Hi PV	-9999 to 30000 Default = 1000	Linear only, Adjustable decimal
Lo PV	-9999 to 30000 Default = 0	
Hi RDG	-99.9 to 999.9 Default = 1000	Linear only, Adjustable decimal
Lo RDG	-99.9 to 99.9 Default = 0	

- **Linear:** This is a linear voltage or current input type. it can be used with any linear output sensor that can be scaled to the linear input voltage range of the Scanner

### Alarm Output Data

ALARMS				
Alarm	Setpoint:	1.0	LATCHED	
Output: 7	Message:	6 Alarm		
Warning Hi			UNLATCHED	
Output: 8	Message:	6 Warning		
Warning Lo			OFF	
Output: NONE	Message:			
Trouble	Setpoint:	-.5	LATCHED	
Output: 9	Message:	6 Trouble		
Deadband:	.2	Deviation:	.5	Delay: 5




## C14 Scan Alarm Operations Manual

---

Field Name	Selections	Notes
Alarm: Warning: Trouble:	O = Off (default)	No Alarm
	L = Latched	If the system is in a <b>Non-Alarming</b> state, the alarm can be acknowledged by pressing the ENTER key from the alarm screen when the Process Alarm indicator is flashing. Reset the alarm by pressing F10 and entering each affected channel number individually. This can also be accomplished by pressing the ALARM RESET button on the Scanner front panel.
	U = Unlatched	Digital output activates on alarm, and deactivates when channel is in a <b>Non-Alarming</b> state. Press ENTER to acknowledge the global alarm.
Alarm Setpoint	-350 to 1400 Default = 1000	Depends on input type Selected.
Alarm Output	N, 1 to 34 Default = NONE	N = NONE
Trouble Setpoint	-350 to 1400 Default = 0	Depends on input type Selected.
Trouble Output	N, 1 to 34 Default = NONE	N = NONE
Hi and Lo Warning Outputs	N, 1 to 34 Default = NONE	N = NONE
Alarm Deadband	0 to 255 Default = 0	See figure below
Alarm Deviation	0 to 255 Default = 25	See figure below
Alarm Delay	0 to 255 Default = 0	See figure below

## C14 Scan Alarm Operations Manual

The diagram below shows the different alarm types.



## ***SYSTEM SETUP***

The System Setup screen enables you to

1. Monitor system errors and reset these errors.
2. View the version and options of your ANASCAN.
3. Protect your screens using passwords
4. Edit various system parameters, such as video control and alarm display screen.
5. Terminate the program.
6. Choose additional options for Start Up sequence
7. Control data logging feature.
8. View the scanner communication status (enabled or disabled).
9. Set the polarity of the digital outputs used for alarms.

The screen is divided into two sections: the left part of the screen is a list of the available windows. An arrow is pointing to the window currently displayed. The right part of the screen displays one of the available windows. Each one contains parameters for editing or viewing. You can view only one window at a time.

Each window, except the System Errors window, can be either Locked or Unlocked. If the window is **Unlocked**, you can change the parameters. If the window is **Locked**, you can only view the parameters. You can unlock a window by entering the password.

### **Getting Here**

Press F3 from the Overview screen.

### System Errors

Screen: System Setup		Group: Eng Test Job: ATI	07-20-98 16:03:43
<div>Current Window: ▶ System Errors System Software Passwords System Parameters System Terminate System Startup Data Logging Scanner Comm Alarm Out Polarity</div>	<div>SYSTEM ERRORS</div> <div>Reset Printer Errors Reset Disk Errors</div>		
<div>PROCESS OK</div>	<div>SYSTEM: OK</div>	<div>No printer errors</div> <div>←↑↓→      PgUpPgDn      ESC Move Cursor    Change Window    Return</div>	

- This window describes any system errors along with the date and time it occurred. It also allows you to reset these errors.
- If a printer error message is displayed, printer data logging is suspended until you reset this error from the window. Similarly, if a disk error message is displayed, disk data logging and status logging is suspended until you reset this error. Communication errors are also displayed on this screen but you cannot reset them.
- If there is a failed communication with a Scanner in the system, ANASCAN will repeatedly retry communicating with the Scanner. While there is failed communication, an error message is displayed. When communication is established, the error message is erased.

System Software

Screen: System Setup

Group: Eng Test Job: ATI

07-20-98 16:04:57

Current Window:  
System Errors  
▶ System Software  
Passwords  
System Parameters  
System Terminate  
System Startup  
Data Logging  
Scanner Comm  
Alarm Out Polarity

SYSTEM SOFTWARE

ANASCAN II  
Version...: 1.13a

Scanners

Scanner	Type	Version
1	CAS16	1.12

PROCESS  
OK

SYSTEM:  
OK

↔

Move Cursor

PgUpPgDn

Change Window

ESC

Return

- This window displays the version and options of the software in the system.
- The upper part of the window displays information about ANASCAN. The lower part displays information about the Scanner.

Passwords

Screen: System Setup

Group: Eng Test Job: ATI

07-20-98 16:05:39

Current Window:  
System Errors  
System Software  
▶ Passwords  
System Parameters  
System Terminate  
System Startup  
Data Logging  
Scanner Comm  
Alarm Out Polarity

PASSWORDS

Editing: LOCKED

	Status	Password
Single Chnl Setup..	UNLOCKED	*****
System Setup Windows		
Passwords.....	AUTOLOCK	*****
System Parameters:	UNLOCKED	*****
System Terminate..	UNLOCKED	*****
System Startup...	UNLOCKED	*****
Data Logging.....	UNLOCKED	*****
Scanner Comm.....	UNLOCKED	*****
Alarm Out Polarity.	UNLOCKED	*****

PROCESS  
OK

SYSTEM:  
OK

Window locked. Enter password to unlock:

↔

Move Cursor

PgUpPgDn


Change Window

ESC

Return

## C14 Scan Alarm Operations Manual

- This window allows you to edit passwords and lock the System Setup windows and some other ANASCAN screens.
- Each window or screen can be either password protected (LOCKED status) or accessible for all (UNLOCKED status).
- The passwords are all set to "PASSWORD" when ANASCAN is shipped. Change the password status and password before running a process.
- Loosing the Passwords may require an on-site service call by Analytical Technology.



### NOTE

Passwords are not required for ANASCAN to function  
However, we recommend that you protect critical screens.

## System Parameters

Screen: System Setup		Group: Eng Test Job: ATI	07-20-98 16:08:11
Current Window: System Errors System Software Passwords ▶ System Parameters System Terminate System Startup Data Logging Scanner Comm Alarm Out Polarity	<div>SYSTEM PARAMETERS</div> <div>Editing: UNLOCKED</div> <div>Video Control</div> <div>High Intensity...: TRUE</div> <div>Video Access....: Direct</div> <div>Alarm Display Screen</div> <div>Auto Switch.....: ON</div> <div>Audible Alarm...: OFF</div>		
PROCESS OK	SYSTEM: OK	Screen Intensity: (T)rue = High, (F)alse = Low <div>←↑↓→ PgUpPgDn</div> <div>Move Cursor Change Window</div> <div>ESC</div> <div>Return</div>	

This window allows you to edit various system parameters as described below.

### Video Control

- **High Intensity.** Set to either **True** or **False**. For most systems containing a CGA monitor or better (as Analytical Technology recommends), set to True. For some LCD or monochrome displays the cursor display and prompt display may not appear correctly. In this case, set to False.
- **Video Access.** Set to either **Direct** access or **BIOS** access. Direct access allows fast screen displays but produces “snow” on some CGA video systems. BIOS access prevents “snow” but is slower.

### Alarm display screen

- **Auto switch,** Set to On or Off. When on, the screen automatically switches to the View Alarms screen whenever a new alarm condition occurs (latched alarms and thermocouple breaks only). This calls maximum attention to an alarm, and Analytical Technology recommends automatic switching for normal operation. When setting up a new process or for a short time, when the process is first started, you may set automatic switching to Off. The large alarm block will still indicate by flashing each new alarm, but the system will not automatically switch to the alarm screen.
- **Audible Alarm.** Set to On or Off. When on, the computer emits an audible warning for each new alarm.

## System Terminate

Screen: System Setup		Group: Eng Test Job: ATI	07-20-98 16:10:21
Current Window:	PROGRAM TERMINATE		
System Errors	Editing: UNLOCKED		
System Software	Terminate Program		
Passwords			
System Parameters			
►System Terminate			
System Startup			
Data Logging			
Scanner Comm			
Alarm Out Polarity			

PROCESS OK	SYSTEM: OK	Press ENTER to terminate program	
		←↑↓→ Move Cursor	PgUpPgDn Change Window
		ESC Return	

- This window allows you to terminate ANASCAN.
- Press **Enter** when the cursor is on the "Terminate Program" message. The program prompts as follows:






### ***Terminate Program (Y/N)***

If you have edited the current job without saving to disk, the following

NOTE: The current job has been changed. To save changes to job file, use the Save Job function of the Job Setup screen before terminating the program.

- The program terminates and returns to the operating system.
- If you terminate the program only for a short time, to change a disk or to fix a computer problem, and safety devices are in process, you can leave the Scanner On.

## System Start Up

Screen: System Setup		Group: Eng Test Job: ATI	07-21-98 8:48:23
Current Window: System Errors System Software Passwords System Parameters System Terminate ▶ System Startup Data Logging Scanner Comm Alarm Out Polarity	<div>PROGRAM STARTUP Editing: UNLOCKED</div> <div>Normal Startup Action.....: Download Job.....: ATI</div> <div>Power Failure Recovery Time Limit.....: 01:00 ( HH:MM ) Under Limit Action: Operator Select Over Limit Action.: Operator Select</div>		
PROCESS OK	SYSTEM: OK	Action for normal startup: (U)pload, (D)ownload, (O)perator select	
		 	 
		Move Cursor	Change Window
		 Return	

This window allows you to set the two start up conditions:

- Normal Start-up
- Power failure recovery:  
under time limit  
over time limit



For each of these conditions, you can select one of three start up actions:

1. **Operator Select.** The program displays the job directory and prompts you for the job to run.
2. **Download Profile.** The program automatically downloads the specified profile.
3. **Upload Profile.** The program automatically uploads the specified profile.


When you choose Download Profile or Upload Profile, you will be asked for a job's name. This can be either a specific job or the last job running when ANASCAN was terminated.

### *Normal start up action*

This is the start up action when the program starts up normally.

### *Power failure recovery*

When the program starts up following a power failure, it determines the time between the power failure and the start up. If the time is less than the power failure recovery time limit, the program takes the under limit start up action. If the time is greater than the power failure recovery time limit, the program takes the over limit start up action. The time limit is entered in hours and minutes.




---

### **NOTE**

In order for the power failure recovery sequence to operate, ANASCAN must be started automatically when the computer is powered up. This is done using an AUTOEXEC.BAT file which contains commands which the computer executes at power up. See DOS operating manual for description of AUTOEXEC.BAT files. The file should contain at its commands:

1. A command to enter the disk directory containing ANASCAN.
  2. A command to start executing the ANASCAN program.
-

## Data Logging



- This window controls the data logging features of ANASCAN.
- Two types of logging are available.
  1. Periodic process variable logging – periodically records the process variables for all the channels in the system.
  2. Alarm logging – records alarm conditions as they occur in the process. Alarms are recorded on alarm occurrence, alarm acknowledge, and alarm clearing.

### Scanner Comm.

Screen: System Setup		Group: Eng Test Job: ATI	07-21-98 9:02:56
<div>Current Window: System Errors System Software Passwords System Parameters System Terminate System Startup Data Logging ►Scanner Comm Alarm Out Polarity</div>	<div>SCANNER COMMUNICATIONS Editing: UNLOCKED  Scanner Communications 1. ENABLED</div>		
<div>PROCESS OK</div>	<div>SYSTEM: OK</div>	Enter scanner 1 communications status: (E)nabled, (D)isabled)	
		<div>↔↑↓↔</div> <div>Move Cursor</div>	<div>PgUpPgDn</div> <div>Change Window</div>
		<div>ESC</div> <div>Return</div>	

- This window allows you to disable or enable the communications to a Scanner.
- Disable the communication if you do not want to send changes to the Scanner.
- When changing the status to Enabled, you are asked whether to download or upload parameters.

### Alarm Output Polarity

Screen: System Setup		Group: Eng Test Job: ATI		07-21-98 9:04:13	
<div>Current Window: System Errors System Software Passwords System Parameters System Terminate System Startup Data Logging Scanner Comm ▶ Alarm Out Polarity</div>		<div>ALARM OUTPUT POLARITY Editing: UNLOCKED  Scanner    State ( On ) 1.        OPEN</div>			
<div>PROCESS OK</div>	<div>SYSTEM: OK</div>	<div>Scanner 1 Alarm Output Polarity With Alarm Output ON:    (O)pen (C)losed  ←↑↓→    PgUpPgDn    ESC Move Cursor    Change Window    Return</div>			

- This window allows you to set the polarity of the digital outputs used for alarms.
- Two options are available when digital output is On.
  1. O – normally open (high)
  2. C – normally closed (low)

# JOB SETUP

The Job Setup screen enables you to

1. Load a job from the disk and download the parameters to the Scanner.
2. Save the currently running job on the disk.
3. Delete a job from the disk.

The Job Setup screen displays a directory of up to 112 job names for each group configured in the SCANINST as a different type number.

## Getting Here

Press F4 from the Overview screen.

The screenshot shows the 'Job Select' screen. At the top, it displays 'Screen:Job Select', 'Group:Eng Test Job:ATI', and the date/time '07-21-98 9:09:09'. The main area is titled 'JOB DIRECTORY' and lists four job names: 'ATI', 'LION', 'TIMET', and 'DEFAULT'. At the bottom, there are several buttons: 'PROCESS OK', 'SYSTEM: OK', 'F1 Load Job', 'F2 Save Job', 'F3 Delete Job', and 'ESC Return'.


Key	Function
TAB	Change to other groups in the system.
F1	Load a job from the disk, and download parameters to the Scanner. If you edited the current job after loading, you will be asked to save before loading.
F2	Save job on disk. If the job name already exists, you will be asked whether to overwrite the existing file.
F3	Delete job from disk.
ESC	Return to Overview screen.

# VIEW ALARMS

The View Alarms screen offers an overview of the alarm and warning conditions by providing detailed information about when they occurred, and were acknowledged, or cleared. This screen also enables you to acknowledge the alarms and warnings.

## Getting Here

Press F5 from the Overview screen



Four possible messages:  
**“Alarm Message”** – alarm has occurred. You see the message defined on the Channel Setup screen.  
**Alarms Acked** – alarms acknowledged from ANASCAN.  
**Remote Acked** – alarms acknowledged from the Scanner.  
**Alarms Reset** – alarms reset from ANASCAN.  
**Remote Reset** – alarms reset from the Scanner.  
**Process Normal** – alarm was cleared.

Possible types:  
**A – Alarm**  
**W – Warning**  
**T - Trouble**

### Function Keys

Key	Function
F1	Clear log. Press after all alarms are acknowledged.
F10	Resets Latched alarms by channel number.
ESC	Return to Overview Screen.

### Alarm Screen Auto Switch

If you set the Auto Switch On in the System Parameters menu, the Alarm screen appears automatically for each new latched alarm. You will be asked to acknowledge each alarm. After doing that you can press Esc to return to the last screen displayed before the alarm condition occurred.

Acknowledging the alarms from View Alarms screen also acknowledges the alarms at the controller. Acknowledging the alarms at the Scanner will acknowledge the alarms on the View Alarms screen.

### Audible Alarm

If you set the Audible Alarm On in the System Parameters menu, the computer emits an audible warning for each new alarm. Press Enter to silence this alarm.

# TREND PLOT


The Trend Plot screen offers graphic trending for both real time and past history of up to 48 hours. Two parameters can be plotted: process variable and setpoint. You can use any combination of these values. You can also combine channels, and plot up to three different channels at the same time.

The screen is a combination of past and real time trend plotting. The past is on the left 5/6 of the screen and the real time is on the right 1/6.

If an EGA video card is installed in the computer, the screen will be colored for easiest identification. If a CGA video card is installed, the plot will be displayed in black and white only.

## Getting Here

Press F7 from the Overview screen or the Channel Setup screen.





### Function Keys

Key	Function
F1	Plot setup. Enter the Plot Setup screen.
F2	Single channel. Display the trend plot for the channel Being edited when you entered the Trend plot screen.
F3	Combine channels. Display the trend plot for the first group of combined channels defined on the Plot Setup screen.
ESC	Return to the screen the trend plot was entered from.

### Trend Plot Setup Screen

The Plot Setup screen allows editing scales and parameters and combining channels.

### Getting Here

Press F1 from the Trend Plot Screen. The screen is shown on the next page.

## C14 Scan Alarm Operations Manual

Information on 8 channels. You cannot edit this part.

Edit here the channel plot range and two parameters of the plot. Press N if you do not wish to plot one of these parameters.

Screen:Plot Setup
Group:Eng Test Job:ATI
07-21-98 9:20:53

Channel	Name	Setpt	PV	Units	Plot Scale		Plot Variables:	
					Low	High	PV	Setpt
1	Ammonia	0	3	PPM	-33.3	100.0	Yes	No
2	Chlorne	.0	.0	PPM	-3.3	10.0	Yes	No
3	Ozone	.00	-.03	PPM	-0.3	1.0	Yes	No
4	Combust	0	3	LEL	-33.3	100.0	Yes	No
5	Combust	0	-0	LEL	-33.3	100.0	Yes	No
6	Chlorne	.0	.1	PPM	-3.3	10.0	Yes	No
7	Oxygen	20.9	20.6	%	16.8	25.0	Yes	No
8	HCl tel	.0	.1	PPM	-6.7	20.0	Yes	No

Trend Plot Window  
 Window Date: 7/20/98  
 Window Time: 23:17  
 Window Size: 12:00

Combined Plot Channels: 1 2 3  
 4 5 6  
 7 8 9  
 8 9 10

Plot Grid....: Yes  
 Print Density: Quad  
 Sample Period: 5 Secs

PROCESS ALARM

SYSTEM: OK

Combined Plot Channels:

←↑↓→ PgUp/PgDn ESC

Move Cursor More Channels Plot Channels

Window parameters: date, time, size.

Combine up to 3 channels in one graphic display. Type in channel numbers separated by spaces.

Values are recorded in periodic intervals according to this time scale. The available range is 1 to 255 seconds.

If you set to YES, the plot will be displayed on a fine grid for a quick referencing.

Indicates the density of the print screens. Set to single, double, or quad

### Print Trend Plot Screen

- To print the Trend Plot screen, you need an IBM graphic compatible printer.
- Press the Print Screen key. The program will ask for a title for the print out.
- Type the title and press Enter. This title will be displayed at the lower center of the screen and will be printed with the plot screen. The printing of the screen at the moment of pressing Enter will be transferred to a buffer and the screen will be printed as a background task. The Trend Plot screen will be updating and other screens may be accessed.
- Be sure your printer is powered and On Line; otherwise, a printer error will appear on the Systems Error window.

## APPENDIX: Input Scaling

All inputs use the automatic scaling function by the  $Mx+B$  calculation. The end points of the calculation are set by HiPV, LoPV, HiRDG, and LoRDG. The default values are set by the input Type selection. Do not change these values until you completely understand the effect.

For Linear inputs, scaling of the input is required to obtain correct engineering units of the input. This must be done before setting SP and Alarm settings.

### Linear Input Scaling

The HiPV and LoPV is the range of the engineering unit, while the HiRDG is the % of the Hi end signal level and the LoRDG is the % of the Lo end signal level.

#### EXAMPLE

##### Situation

A gas sensor that generates a 4-20 milliamp signal is connected to the Scanner. The specifications of the sensor state that it generates 4 milliamps at 0.0 PPM and 20 mA at 50.0 PPM.

##### Setup

The sensor measures PPM in tenths, so the appropriate display format is -999.9 to +3000.0.

This table shows the input readings.

PV Displayed	Sensor Input	Reading (%FS)
50.0 PPM	20 mA	100%
0.0 PPM	4 mA	$100\% \times (4\text{ma}/20\text{ma}) = 20\%$

The scaling values are therefore:

Parameter	Low Value	High Value
Process Value (PV)	0.0 PPM	50.0 PPM
Input Reading (RDG)	20.0%	100.0%